



ERTMS Level 2


Vertrekken

ETCS Level 2 infrastructuur



Rijden met ERTMS Level 2






ERTMS_ _ _




ERTMS_ _ _

DMI (Driver Machine Interface) onder ERTMS



Start of Mission (SoM)



RIJDEN



FS = Full Supervision



OS = On Sight



SR = Staff Responsible

STARTEN



SB = Stand By